

# DIVERTER TRIM INSTALLATION

Model #:  
10105



## BEFORE YOU BEGIN YOUR INSTALLATION:

1



Turn off water supply.

2



Observe all local  
plumbing codes.

3



Inspect plumbing for signs of  
damage. Replace as necessary.

4



**DO NOT** use petroleum based  
products on this faucet.

## REQUIRED TOOLS AND MATERIALS:



Phillips Screwdriver



Adjustable Wrench



Hex Key Wrench



Socket Wrench

**WARNING:** Cancer and reproductive harm - see [www.P65Warnings.ca.gov](http://www.P65Warnings.ca.gov)

### IMPORTANT!

- Read these instructions and plan the installation before beginning.
- Risk of product damage. Do not apply direct heat to the valve. Excessive heat will damage the plastic components and plaster guard.
- Do not remove the plaster guard until instructed to do so.
- A water supply is required for this valve.
- Component location, spacing, and situational requirements can vary.

