


Installation Guide | Round Industrial Rain Shower Heads Model # RS256-1, RS256-2, RS256-3, RS256-4, RS256-5, RS256-6



CAUTION: To prevent burns, set the valve's water temperature to 120°F (49°C) or lower. Check the valve's temperature guide. NOTE: Pick a valve with a suitable flow rating for safety at low flow rates. Adhere to local plumbing and building standards.

- 1. Use sealing tape.
- 2. Flush water to remove debris.
- 3. Occasionally clean nozzles during water flow.
- 4. Regularly wash away debris from the screen washer.

If you need additional assistance, don't hesitate to reach out to our Customer Service team at 1-888-304-0660. They are available Monday - Friday 6:00 am to 5:00 pm PST.

Please refer to the separate Service Parts Documents for available replacement parts.

Note: For Ceiling Installation only. Recommended cross beam support above the ceiling for Flange support.

