

FREESTANDING TUB ROUGH-IN VALVE INSTALLATION

Model #:
10123



BEFORE YOU BEGIN YOUR INSTALLATION:

1



Turn off water supply.

2



Observe all local plumbing codes.

3



Inspect plumbing for signs of damage. Replace as necessary.

4



DO NOT use petroleum based products on this faucet.

REQUIRED TOOLS AND MATERIALS:



Flat Screwdriver




Adjustable Wrench



Channel Locks



Thread Sealant



Drill



1/4" Hex Key Wrench

WARNING: Cancer and reproductive harm - see www.P65Warnings.ca.gov

IMPORTANT!

- Read these instructions and plan the installation before beginning.
- Risk of product damage. Do not apply direct heat to the valve. Excessive heat will damage the plastic components and plaster guard.
- Do not remove the plaster guard until instructed to do so.
- A hot and cold water supply is required for this valve.
- Component location, spacing, and situational requirements can vary.

FLOOR INSTALLATION

1.

FINISHED FLOOR

MAX: 4-5/8"
MIN: 3-5/8"

JOIST

STRINGER

Before installation, determine the height of the valve position on stringer. ATTENTION: The support lumbar should be no less than 2" thick or 6" wide (2x6 lumber not sufficient).

2.

3/8" OR 1/2" DIA. HOLES

After determining valve height, place the valve in the desired position on the stringer. For ease of trim installation, we recommend keeping the finished floor within 3-5/8" to 4-5/8" to bottom of rough-in. Allow enough room for supply pipes.

3.

Install hot and cold supply lines into the rough-in valve.

COLD

HOT

4.

Ensure rough-in plug is installed, check to make sure shut off valves are closed.

CAP SCREW

PLUG

5.

OFF POSITION

Shut off valve is in the off position when the screw is perpendicular to supply inlet.

6.

Place mud guard on valve.

NOTICE: Install tub filler 21 inches away from any finished wall to avoid collision with tub filler moving parts.